

CIRCUIT BOARD  
HK61EA005 used in

[PRINT](#)

Model (85) and Item

<a href="#">40FKA002...300..</a>	36
<a href="#">40FKA002...310..</a>	36
<a href="#">40FKA003...300..</a>	36
<a href="#">40FKA003...310..</a>	36
<a href="#">40FKA005...300..</a>	36
<a href="#">40FKA005...310..</a>	36
<a href="#">40FKA006...300..</a>	36
<a href="#">40FKA006...310..</a>	36
<a href="#">40FKB002...300..</a>	35
<a href="#">40FKB003...300..</a>	35
<a href="#">40FKB005...300..</a>	35
<a href="#">40FKB006...300..</a>	35
<a href="#">FK4CNB006000AAAA</a>	42
<a href="#">FK4CNB006000AEAA</a>	42
<a href="#">FK4CNB006000AFAA</a>	42
<a href="#">FK4CNB006000AGAA</a>	39
<a href="#">FK4CNB006000AHAA</a>	39
<a href="#">FK4CNF001000AAAA</a>	42
<a href="#">FK4CNF001000AEAA</a>	33
<a href="#">FK4CNF001000AFAA</a>	33
<a href="#">FK4CNF001000AGAA</a>	34
<a href="#">FK4CNF001000AHAA</a>	34
<a href="#">FK4CNF002000AAAA</a>	42
<a href="#">FK4CNF002000AEAA</a>	33
<a href="#">FK4CNF002000AFAA</a>	33
<a href="#">FK4CNF002000AGAA</a>	34
<a href="#">FK4CNF002000AHAA</a>	34
<a href="#">FK4CNF003000AAAA</a>	42
<a href="#">FK4CNF003000AEAA</a>	33
<a href="#">FK4CNF003000AFAA</a>	33
<a href="#">FK4CNF003000AGAA</a>	34
<a href="#">FK4CNF003000AHAA</a>	34
<a href="#">FK4CNF005000AAAA</a>	42
<a href="#">FK4CNF005000AEAA</a>	33
<a href="#">FK4CNF005000AFAA</a>	33
<a href="#">FK4CNF005000AGAA</a>	34

[FK4CNF005000AHAA](#) 34  
[FK4DNB003000AAAA](#) 44  
[FK4DNB005000AAAA](#) 44  
[FK4DNB006000AAAA](#) 44  
[FK4DNF001000AAAA](#) 34  
[FK4DNF002000AAAA](#) 34  
[FK4DNF003000AAAA](#) 34  
[FK4DNF005000AAAA](#) 34  
[FV4ANB006000AAAA](#) 32  
[FV4ANB006000ABAA](#) 38  
[FV4ANB006000ACAA](#) 38  
[FV4ANB006000ADAA](#) 38  
[FV4ANF002000AAAA](#) 32  
[FV4ANF002000ABAA](#) 38  
[FV4ANF002000ACAA](#) 38  
[FV4ANF002000ADAA](#) 38  
[FV4ANF003000AAAA](#) 32  
[FV4ANF003000ABAA](#) 38  
[FV4ANF003000ACAA](#) 38  
[FV4ANF003000ADAA](#) 38  
[FV4ANF005000AAAA](#) 32  
[FV4ANF005000ABAA](#) 38  
[FV4ANF005000ACAA](#) 38  
[FV4ANF005000ADAA](#) 38  
[FV4BNB003000AAAA](#) 32  
[FV4BNB003T00AAAA](#) 32  
[FV4BNB005000AAAA](#) 32  
[FV4BNB005T00AAAA](#) 32  
[FV4BNB006000AAAA](#) 32  
[FV4BNB006T00AAAA](#) 32  
[FV4BNF002000AAAA](#) 38  
[FV4BNF002T00AAAA](#) 38  
[FV4BNF003000AAAA](#) 38  
[FV4BNF003T00AAAA](#) 38  
[FV4BNF005000AAAA](#) 38  
[FV4BNF005T00AAAA](#) 38  
[FV4CNB003T00AAAA](#) 42  
[FV4CNB005T00AAAA](#) 42  
[FV4CNB006000AAAA](#) 42  
[FV4CNB006T00AAAA](#) 42  
[FV4CNF002000AAAA](#) 42

[FV4CNF002T00AAAA](#) 42  
[FV4CNF003000AAAA](#) 42  
[FV4CNF003T00AAAA](#) 42  
[FV4CNF005000AAAA](#) 42  
[FV4CNF005T00AAAA](#) 42  
[PF1MNA071000ACAA](#) 22  
[PF1MNA071000ADAA](#) 22  
[PF1MNB071000AAAA](#) 34